

Lovibond® Water Testing

Tintometer® Group



TB 211 IR

with USB interface



The compact Lovibond® infrared turbidity measuring instrument TB 211 IR for fast and accurate on-site analysis. It is measured as provided in EN ISO 7027, the scattered light at an angle of 90 °. The wide measuring range from 0.01 to 1100 TE / F = NTU = FNU with a detection limit of 0.01 NTU allows the use of the device in different areas, from drinking water to wastewater.

Since the measurements are made by means of infrared light, both colored and colorless water samples can be measured. A direct transfer of the measurement results to a PC is through the USB interface TB 211 IR easy to set up. The necessary USB cable is already part of the delivery.

- USB interface
- Range 0.01 - 1100 NTU
- Measurement according to EN ISO 7027
- Measurement with infrared light at an angle of 90 °

Part Number: 266030

Industry

Chemical Industry | Industries Others | Marine Industry | Municipalities | NGO | Oil and Gas | Pool Public | Pool Services

TB 211 IR

A compact instrument for reliable and easy determination of turbidity. A ring memory with 125 data sets and a USB interface guarantee an efficient data management.

Measuring Range

Test Name	Measuring Range
Turbidity	0.01 - 1100 NTU

Technical Data

Optics	temperaturecompensated LED (λ = 860 nm) and photosensor amplifier in water proof sample chamber, infrared light
Accuracy	$\pm$ 2.5 % of reading, or $\pm$ 0.01 NTU, whichever is bigger, in the range of 0.01 - 500 NTU ; $\pm$ 5 % of reading in the range of 500 - 1000 NTU
Operation	polycarbonate membrane, splash proof
Display	backlit LCD
Suitable Vials	Round Cuvettes 24 mm
Interfaces	Micro-USB
Internal Storage	internal ring memory for 125 data sets
Power Supply	9 V-block
Auto – OFF	Yes
Measuring Principle	nephelometric (90° scattered light)
Measuring Range	0,01-1100 NTU (Autorange)
Clock	Real Time Clock and Date
Portability	Portable
Environmental Conditions	5 - 40 °C at 30 - 90 % relative humidity (non condensing)
Compliance	CE
Dimensions	110 x 55 x 190 mm
Weight	400 g (Basic unit)
Weight with Packaging	(Basic unit)

Delivery Scope

- Instrument in carrying case
- 4 turbidity standards (< 0,1, 20, 200 and 800 NTU)
- 9 V battery
- 2 vials (ø 24 mm) with lids
- USB cable 1.5 m
- Warranty information
- Certificate of Compliance
- Instruction Manual

Accessories

Title	Part Number
Formazin Stock Solution (4000 NTU), 125 ml	194141
Formazin Stock Solution (4000 NTU), 250 ml	194142
Set turbidity standards T-CAL (<0.1, 20, 200, 800 NTU)	194150
Battery 9 V	1950012
Cleaning cloth	197635
Sample cuvettes with black lid, Height 55 mm, ø 24 mm, set of 12	197655
Sample chamber lid	19801119
USB cable 1.5 m, for TB 211 IR	19802509

Tintometer GmbH
 Lovibond® Water Testing
 Schleefstraße 8-12
 44287 Dortmund
 Tel.: +49 (0)231/94510-0
 Fax: +49 (0)231/94510-30
 sales@lovibond.com
 www.lovibond.com
 Germany

The Tintometer Limited
 Lovibond House
 Sun Rise Way
 Amesbury, SP4 7GR
 Tel.: +44 (0)1980 664800
 Fax: +44 (0)1980 625412
 sales@lovibond.uk
 www.lovibond.com
 UK

Tintometer China
 Room 1001, China Life Tower
 16 Chaoyangmenwai Avenue,
 Beijing, 100020
 Tel.: +86 10 85251111 App. 330
 Fax: +86 10 85251001
 chinaoffice@tintometer.com
 www.lovibond.com
 China

Tintometer South East Asia
 Unit B-3-12, BBT One Boulevard,
 Lebuhi Nilam 2, Bandar Bukit Tinggi,
 Klang, 41200, Selangor D.E
 Tel.: +60 (0)3 3325 2285/6
 Fax: +60 (0)3 3325 2287
 lovibond.asia@tintometer.com
 www.lovibond.com
 Malaysia

Tintometer Brazil
 Caixa Postal: 271
 CEP: 13201-970
 Jundiaí – SP
 Tel.: +55 (11) 3230-6410
 sales@tintometer.com.br
 www.lovibond.com.br
 Brazil

Tintometer Inc.
 6456 Parkland Drive
 Sarasota, FL 34243
 Tel: 941.756.6410
 Fax: 941.727.9654
 sales@lovibond.us
 www.lovibond.com
 USA

Tintometer India Pvt. Ltd.
 Door No: 7-2-C-14, 2nd, 3rd & 4th Floor
 Sanathnagar Industrial Estate,
 Hyderabad, 500018
 Telangana
 Tel: +91 (0) 40 23883300
 Toll Free: 1 800 599 3891/ 3892
 indiaoffice@tintometer.com
 www.lovibondwater.in
 India

Tintometer Spain
 Postbox: 24047
 08080 Barcelona
 Tel.: +34 661 606 770
 sales@tintometer.es
 www.lovibond.com
 Spain

Technical changes without notice
 Printed in Germany

Lovibond® and Tintometer® are Trademarks of the Tintometer Group of Companies